







## Zestaw adapterów i złączek dokręcanych ręką ADT103

Adaptory ze szybkimi złączami ADT103-NPT				
	Model	Opis	Max ciśnienie	Rysunek
	ADT100-NPTM4-NPTF8Q	Adapter 1/4NPT zewn. na 1/8NPT wew.	1000bar	
	ADT100-NPTM4-NPTF4Q	Adapter 1/4NPT zewn. na 1/4NPT wew.	1000bar	
	ADT100-NPTM4-NPTF2Q	Adapter 1/4NPT zewn. na 1/2NPT wew.	1000bar	
	ADT100-NPTM4-BSPF8Q	Adapter 1/4NPT zewn. na 1/8BSP wew.	1000bar	
	ADT100-NPTM4-BSPF4Q	Adapter 1/4NPT zewn. na 1/4BSP wew.	1000bar	
	ADT100-NPTM4-BSPF3Q	Adapter 1/4NPT zewn. na 3/8BSP wew.	1000bar	
	ADT100-NPTM4-BSPF2Q	Adapter 1/4NPT zewn. na 1/2BSP wew.	1000bar	
	ADT100-NPTM4-M10FQ	Adapter 1/4NPT zewn. na M10x1 wew.	1000bar	
	ADT100-NPTM4-M14FQ	Adapter 1/4NPT zewn. na M14x1,5 wew.	1000bar	
ADT100-NPTM4-M20FQ	Adapter 1/4NPT zewn. na M20x1,5 wew.	1000bar		

Adaptory ze szybkimi złączami ADT103-BSP				
	Model	Opis	Max ciśnienie	Rysunek
	ADT100-BSPM4-NPTF8Q	Adapter 1/4BSP zewn. na 1/8NPT wew.	1000bar	
	ADT100-BSPM4-NPTF4Q	Adapter 1/4BSP zewn. na 1/4NPT wew.	1000bar	
	ADT100-BSPM4-NPTF2Q	Adapter 1/4BSP zewn. na 1/2NPT wew.	1000bar	
	ADT100-BSPM4-BSPF8Q	Adapter 1/4BSP zewn. na 1/8BSP wew.	1000bar	
	ADT100-BSPM4-BSPF4Q	Adapter 1/4BSP zewn. na 1/4BSP wew.	1000bar	
	ADT100-BSPM4-BSPF3Q	Adapter 1/4BSP zewn. na 3/8BSP wew.	1000bar	
	ADT100-BSPM4-BSPF2Q	Adapter 1/4BSP zewn. na 1/2BSP wew.	1000bar	
	ADT100-BSPM4-M10F8Q	Adapter 1/4BSP zewn. na M10x1 wew.	1000bar	
	ADT100-BSPM4-M14F4Q	Adapter 1/4BSP zewn. na M14x1,5 wew.	1000bar	
ADT100-BSPM4-M20F2Q	Adapter 1/4BSP zewn. na M20x1,5 wew.	1000bar		

Adaptory ze szybkimi złączami ADT103-M20				
	Model	Opis	Max ciśnienie	Rysunek
	ADT100-M20M-NPTF8Q	Adapter M20x1,5 zewn. na 1/8NPT wew.	1000bar	
	ADT100-M20M-NPTF4Q	Adapter M20x1,5 zewn. na 1/4NPT wew.	1000bar	
	ADT100-M20M-NPTF2Q	Adapter M20x1,5 zewn. na 1/2NPT wew.	1000bar	
	ADT100-M20M-BSPF8Q	Adapter M20x1,5 zewn. na 1/8BSP wew.	1000bar	
	ADT100-M20M-BSPF4Q	Adapter M20x1,5 zewn. na 1/4BSP wew.	1000bar	
	ADT100-M20M-BSPF3Q	Adapter M20x1,5 zewn. na 3/8BSP wew.	1000bar	
	ADT100-M20M-BSPF2Q	Adapter M20x1,5 zewn. na 1/2BSP wew.	1000bar	
	ADT100-M20M-M10FQ	Adapter M20x1,5 zewn. na M10x1 wew.	1000bar	
	ADT100-M20M-M14FQ	Adapter M20x1,5 zewn. na M14x1,5 wew.	1000bar	
ADT100-M20M-M20FQ	Adapter M20x1,5 zewn. na M20x1,5 wew.	1000bar		