

Zestaw wysokociśnieniowych adapterów i złączek ADT104-HP



Adaptery z gwintem zewnętrznym 1/4HP (Autoclave M-250-C) na różne inne przyłącza (17szt + walizka)

Model	Opis	Max ciśnienie	Rysunek
ADT100-HPM-M14F	Adapter z gwintem zewn. 1/4HP na gwint wewn. M14x1,5.	2500bar	
ADT100-HPM-M20F	Adapter z gwintem zewn. 1/4HP na gwint wewn. M20x1,5.	2500bar	
ADT100-HPM-BSP4F	Adapter z gwintem zewn. 1/4HP na gwint wewn. 1/4BSP.	2500bar	
ADT100-HPM-BSP3F	Adapter z gwintem zewn. 1/4HP na gwint wewn. 3/8BSP.	2500bar	
ADT100-HPM-BSP2F	Adapter z gwintem zewn. 1/4HP na gwint wewn. 1/2BSP.	2500bar	
ADT100-HPM-NPT4F	Adapter z gwintem zewn. 1/4HP na gwint wewn. 1/4NPT.	1000bar	
ADT100-HPM-NPT2F	Adapter z gwintem zewn. 1/4HP na gwint wewn. 1/2NPT.	1000bar	
ADT100-HPM-M14M	Adapter z gwintem zewn. 1/4HP na gwint zewn. M14x1,5.	2500bar	
ADT100-HPM-M20M	Adapter z gwintem zewn. 1/4HP na gwint zewn. M20x1,5.	2500bar	
ADT100-HPM-BSPM4	Adapter z gwintem zewn. 1/4HP na gwint zewn. 1/4BSP.	2500bar	
ADT100-HPM-BSPM3	Adapter z gwintem zewn. 1/4HP na gwint zewn. 3/8BSP.	2500bar	
ADT100-HPM-BSPM2	Adapter z gwintem zewn. 1/4HP na gwint zewn. 1/2BSP.	2500bar	
ADT100-HPM-NPTM4	Adapter z gwintem zewn. 1/4HP na gwint zewn. 1/4NPT.	1000bar	
ADT100-HPM-NPTM2	Adapter z gwintem zewn. 1/4HP na gwint zewn. 1/2NPT.	1000bar	
ADT100-HPM-HPMM4	Adapter z gwintem zewn. 1/4HP na gwint zewn. 1/4HP.	2500bar	